Installation Manual SGL-0600 Version 1.0.0



• Single Zone Control

SGL-0600

HBX Control Systems Inc.

Control Systems Inc.

HBX SGL-0600 Single Zone Control Version 1.0.0

TABLE OF CONTENTS

HBX

Introduction	1-3
Description	1
Safety Symbols & Warnings	2
Receipt & Inspection	2
Technical Data and Dimensions	3
Wiring & Installation	4-25
Wiring	4
Installation	5
Naviaatina the THM-0600	6
Setting the THM-0600	
Application Drawings	19-20
Warranty Information	21





HBX SGL-0600 SINGLE ZONE MODULE

Control Systems Inc.

HB)

The HBX Single Zone (SGL-0600) is designed to control most common HVAC systems and provides flexibility to integrate Heating or cooling systems with multiple devices including forced air heating and cooling, infloor heating/cooling, heat pumps, fancoils and humidifier/dehumidifier.

The Single Zone includes a Wi-Fi Enabled Full-Colour touchscreen thermostat (THM-0600) and relay box to control your heating and cooling equipment. The THM-0600 thermostat is a 2 wire (power and communication) thermostat which makes it ideal for retrofits by re-using the existing 2 wire electrical to solve the issue of not having enough wires to upgrade systems.

The single zone relay box allows user to control up to 2 stages of heating and 2 stages cooling with the ability to control humidity and fan control. The zone box also allows for 2 dry demand outputs to heating and cooling devices. Wiring the relay box only requires 24V (low voltage) to power the unit.



This control can also function as a stand alone system without WiFi capabilities.



FEATURES

- App for Android or Apple Smartphone/tablet device for remote access with alarm email notification
- 2 wire communication thermostat
- Humidity and Fan Control
- Up to 2 stage heating and 2 stage cooling
- Two (2) dry demands outputs
- Can be added with the SGL-0600 for additional fancoil output



This point clarifies pertinent information, or brings your

attention to an action that may have adverse effects on

Refer to the specified electrical or mechanical drawing at

SAFETY SYMBOLS



Extreme Hazard

This action poses a serious threat that could result in personal injury or death, as well as permanent damage to the equipment. Proceed with caution.



Moderate Hazard

This action may cause personal injury or have adverse effects on the installation process if handled incorrectly.



Disconnect Power Source

The presence of low voltage(24VAC) or high voltage(120VAC) could result in personal injury or permanent damage to components or equipment.

SAFETY WARNINGS



WARNING: Non-serviceable product. Send to HBX Controls Inc. only for service.



WARNING: Only suitably qualified individuals with formal training in electrical and hydronic controls should attempt the installation of this equipment. Incorrect wiring and installation will affect the warranty provided with this unit. Wiring must be completed in accordance with the codes and practices applicable to the jurisdiction for the actual installation.

Point of Interest

the installation process.

the back of the manual.

Drawing Reference



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



EXTREME HAZARD: The **HBX SGL-0600** is a microprocessor based controller and as such is not to be regarded as a safety (limit) control. Please consult and install the heating or cooling appliance in accordance with the manufacturer's recommendations.



WARNING: Use only copper conductor supply wire suitable for at least 105 °C



WARNING: a) Use copper conductors only if the terminal is acceptable only for connections to copper wire; b) Use aluminum conductors only or use aluminum or copper-clad aluminum condctors only if the terminal is acceptable only for connection to aluminum wire; or c) use copper or aluminum conductors or use copper, copper-clad aluminum, or aluminum conductors if the terminal is acceptable for connection to either copper or aluminum wire.





WARNING: THM-0600 only for use with SGL-0600

RECEIPT & INSPECTION

After receiving, inspect the unit for any possible physical damage that may have occurred during transportation. After unpacking the unit make sure the box contains:

• 1 x Thermostat THM-0600

- 1 x Thermostat Wall Cutout Template
- 1 x SGL-0600
- 1 x Terminal Screwdriver (2.5 mm)



TECHNICAL DATA AND DIMENSIONS

SGL-0600 TECHNICAL DATA



Specifications:

7 x Triac Outputs 0.500mA max 2 x Dry Contact Demand Relays 24VAC 0.5A Max 1x Input 24VAC +/- 10% 50/60Hz 2A Max

Combined relay power should not exceed 2A

Weight: 0.220 Kg

Dimensions: 100mm W x 120mm H x 38mm 3.9in W x 4.7in H x 1.5in

Listings: FCC ID: 2AHMRESP125

Storage: 50°F to 104°F (10°C to 40°C)

WiFi:

2.4GHz Network Only

DIMENSIONS







WIRING AND INSTALLATION

WIRING

We recommend all signal wiring to be a minimum of 18AWG shielded wire at a maximum of 500ft.



1. THERMOSTAT INPUTS

1, 2: Input for THM-0600

2. DEMAND OUTPUTS

5, 6: Demand 1: closes during calls for either heating or cooling depending on the Type7, 8: Demand 2: closes during calls for either heating or cooling depending on the Type

3. INPUTS

8: RC: 24VAC input for Y1 and Y2 9, 10: R,C: input power for SGL-0600 and 24VAC input for W1, W2, G and X.

WARNING: Class 2 curcuits only

4. OUTPUTS

- 1: W1: first stage heating
- 2: W2: second stage heating
- **3:** G: Fan control output **5:** X: Humidity control output
- 6: Y1: first stage cooling
- 7: Y2: second stage cooling



INSTALLATION

SGL-0600 Installation

Control Systems Inc.

The SGL-0600 is designed to be wall mounted or installed in a separate electrical enclosure. The unit should be installed indoors and protected from falling water and high humidity conditions. With all the covers in place, it is designed to protect any individual from accidental electrical shock. It is not suitable for installation in hazardous locations and should not be close to any electromagnetic fields.

- Identify the four mounting holes on the SGL-0600, mark on the wall the desired location of mounting
- Pre-drill, anchor and fasten the two bottom screws for mounting
- Hang SGL-0600 and fasten the top two screws then tighten the bottom screws
- Complete wiring connections in accordance with local area electrical codes

The THM-0600 is the only approved thermostat to be used with the SGL-0600. Do not supply external power to the thermostat.



Wiring polarity is important. Match the ground and TH on the THM-0600 to the SGL-0600 control.

Thermostat field signal wiring installation

The signal wiring that connects the SGL-0600 to each thermostat should not run parallel for any lengths with any other wires. If this is a retrofit installation and the thermostat signal wiring installation can not be verified it is recommended that the thermostats to be installed in the mechanical room with remote room (029-0022, not provided) and/or floor sensors (029-0045) [not provided].



In order to assure proper room temperature, it is important to identify the ideal location of the thermostat. It should be approximately 5 feet from the floor and at least 1 foot from door openings on an interior wall. Avoid exposing the thermostat to direct sunlight, to air flows (doors, windows, etc.) as well as to heat sources. Ensure the cavity that the thermostat will be installed in is well insulated.

Use a screwdriver to gently pop the front cover off from the top of the thermostat, and then remove the front to expose wiring terminals.

Do not use the screwdriver on the bottom of the thermostat. This can cause damage to the THM-0600



External Room Thermistor

On the THM-0600, the room thermistor switch is located on the bottom left corner of the thermostat.

Toggling this switch will allow the user to alternate between the built in room thermistor on the THM-0600, or an external room thermistor connected to pins 1 and 2 on the THM-0600.



PROGRAMMING THM-0600

Navigating the Thermostat

The touchscreen of this thermostat makes it easy to change used settings. Touch any item to adjust its setting excluding the time on the home screen.

Simply touch the temperature to adjust your desired target temperature. Pressing the menu icon on top right corner allows you to view the main "Setup Menu" options. Pressing the back icon allows you to return to the home screen or setup menu.

Touching the area below the current temperature allows you to see what current demands are present.

Setting the Thermostat

Special Functions

Enter the **"Special Functions"** screen by touching and holding down the menu icon for 5 seconds (from the status screen). To select the desired option, simply touch any item to adjust it's setting.



Lockout Thermostat

On the main screen press and hold the time (clock) for 20 seconds. The lock icon will appear in the top right corner.

Unlock Thermostat

Repeat the same process as locking the thermostat. Press and hold the time (clock) on the top left corner on the main screen for 20 seconds. The lock icon \square on the screen will go away.

Sync Code

This number is the identifier used in the HBX ThermoLinx App to connect to your thermostat.



<

Stat Type

Priority

Demand Type

Heat Only

Low

None

No settings will be able to be changed when the thermostat is locked. Only on the Thermolinx mobile app you will have the ability to still make changes. When the Thermostat is locked, only minimal temperature target adjustment can be made. $2^{\circ}C/3^{\circ}F$ above/under.





Type - Select between Heating, Cooling, and a variety of combined modes.

C Special Fun	ctions
Stat Type	Heat Only
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

Special Funct ATHM-0000	tions
Stat Type	Cool Only
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

< Special Fun ATHM-00	nctions
Stat Type	Heat and Cool
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

Special Fur ATHM-00	octions
Stat Type	2 Stage Heat
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

< Special Fur ATHM-00	nctions
Stat Type	2 Stage Cool
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

Heat Only Function

Select the "Heat Only Function" for applications using a single heating source. This type will turn on W1 and Demand 1 and 2.

Cool Only Function

Select the "Cool Only Function" for applications using a single cooling source. This type will turn on Y1 and Demand 1 and 2.

Heat and Cool Function

Select the "Heat and Cool Function" for applications using a single heating source and a single cooling source. This type will turn on W1 and Demand 1 for heat and Y2 Demand 2 for cool.

2 Stage Heat Function

Select the "2 Stage Heat Function" for applications using 2 stage heating. This type will turn on W1, W2 and Demand 1 and 2.

2 Stage Cool Function

Select the "2 Stage Cool Function" for applications using 2 stage cooling. This type will turn on Y1, Y2 and Demand 1 and 2.



Stat Type 2 Heat with Cool THM Mode Air Aux Sensor Floor Room Offset 0° Fancoil Setup >

HBX

< Special FL ATHM-0	Inctions
Stat Type	2 Cool with Heat
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

2 Heat with Cool Function

Select the "2 Heat with Cool Function" for applications using 2 stage heating and 1 stage cooling. This type will turn on W1, W2 and Demand 1 for heat and Y2 and Demand 2 for cool.

2 Cool with Heat Function

Select the "2 Cool with Heat Function" for applications using 2 stage cooling and 1 stage heating. This type will turn on Y1, Y2 and Demand 2 for cool and W1 and Demand 1 for heat.

Special Functions ATHM-0000 Stat Type 2 Heat and 2 Cool THM Mode Air Aux Sensor Floor Room Offset 0° Fancoil Setup >

2 Heat and 2 Cool Function

Select the "2 Heat and 2 Cool Function" for applications using 2 stage heating and 2 stage cooling. This type will turn on W1, W2 and Demand 1 for heat and Y1, Y2 and Demand 2 for cool.



Mode - This option allows you to select between Air, Floor and Dual sensor modes

Special Functions	
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>
4-Pipe Geo	OFF
Room Name Setup	>
Default Setup	>

Special Functions ATHM-0000	
THM Mode	Floor
Aux Sensor	Floor
Differential	6°
Room Offset	0°
Fancoil Setup	>
4-Pipe Geo	OFF
Room Name Setup	>

Special Functions ATHM-0000	
THM Mode	Floor
Aux Sensor	Floor
Differential	6°
Room Offset	0°
Fancoil Setup	>
4-Pipe Geo	OFF
Room Name Setup	>

Air

Thermistor within the thermostat sensing temperature providing feedback for the specific room or zone being controlled by the thermostat

Floor

Sensor temperature providing feedback from the floor surface to the thermostat. This mode will run the thermostat on floor temperature only. Aux sensor will automatically be set to floor.



Only available when heating modes are the primary function. Must have floor sensor connected.

Floor Mode: Differential

When in floor mode, the differential option is set to allow a differential around the target to reduce the chances of short cycling. Ex. A differential of 4°F is 2°F above the setpoint and 2°F below the setpoint.

Ex. A differential of 4°F is 2°F above the setpoint and 2°F below the setpoint.



 Special Functions

 THM Mode
 Dual

 Aux Sensor
 Floor

 Floor Min
 70°

 Floor Max
 80°

 Room Offset
 -20°

 Fancoil Setup
 >

 4-Pipe Geo
 OFF

Special Functions ATHM-0000 THM Mode Dual Aux Sensor Floor Floor Min 70° Floor Max 80° Room Offset -20° Fancoil Setup > 4-Pipe Geo OFF

Dual

Sensor temperature providing feedback for both the air temperature and floor sensor temperatures. Aux sensor will automatically be set to floor



Only available when heating modes are the primary function. Must have floor sensor connected.

Dual Mode: Floor Min/Max

Floor Max - The thermostat will not allow the floor temperature to go above this value, protecting the integrity of the floor covering.

Floor Min - The thermostat will not allow the floor temperature to go below this value

Aux Sensor - Auxiliary thermistor

C Special Func	tions
Stat Type	Heat Only
Demand Type	Low
Priority	None
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

None – No external thermistor attached.
Floor – Displays the floor temperature using external 1 sensor
Room - Disregards internal sensor, uses external
Outdoor – Uses external sensor to display outdoor temperature
RM/Ave – Averages auxiliary sensor and internal sensor, or optional external room sensor
Floor Ave – Averages auxiliary and optional external floor sensor in lieu of room sensor



When using the external room/floor sensor on pins 1 and 2 ensure the dipswitch is set to external.



Room Offset - This feature allows you to program an offset. In the case that the thermostat is not reading the same temperature as the actual temperature in the room.

C Special Func	tions
Stat Type	Heat Only
Demand Type	Low
Priority	None
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>

Special Func

Air

Floor

0°

>

OFF

>

>

OFF

15 mins

THM Mode

Aux Sensor

Room Offset

Fancoil Setup

4-Pipe Geo

Default Setup

Fan ON Demand

Stage Delay

Fancoil Setup

Password

Example Actual Room Temperature 72 °F. Direct Sunlight causes Thermostat to show 78 °F. The user can put an offset of -6 °F to get the temperatures to match.

Minimum value -20°F Maximum value 20°F

Fancoil Setup - This setting takes you to the Fancoil Setup Menu.

If you are utilizing a fancoil, you will have access to the following settings:

Fan On Demand Stage Delay

Fancoil Setup: Fan On Demand This option will turn the fan on with any fancoil demand.



Fancoil Setup: Stage Delay

Use this setting to adjust the lagtime between stage 1 and stage 2. This option is only available when 2 heating or cooling stages are selected.

```
Default - 15m
Range - 1m - 240m
```



Room Name Setup - This menu allows for the option to select preset names for the THM-0600.

Special Function ATHM-0000	ons
Stat Type	Heat Only
Demand Type	Low
Priority	None
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Room Name Setu	ip >

Room Number - sets the number associated with the name. Range 0-9
Name - sets the name of the thermostat. Kitchen, Living Room, Bathroom, Bedroom, Basement, Guest Room, Main Floor, Office, Upstairs, DHW Tank.
Press To Save Name - once the number and name is set hit this option to save the information.

Default Setup - Restores the thermostat to factory default settings or previously saved settings.

C Special Functions	
THM Mode	Air
Aux Sensor	Floor
Room Offset	0°
Fancoil Setup	>
4-Pipe Geo	OFF
Default Setup	>
Password	>

Save Current Settings - This option will save the current settings in the event the settings get changed in the future.
 Load Current Settings - This options will load the last saved current settings.
 Factory Reset - Reset all settings back to default.



Setup Menu

Enter the **"Setup Menu"** screen by touching the menu icon. To select the desired option, simply touch any item to adjust it's setting.

Schedules - Allows themostat temperatures to be scheduled up to 4 time periods for weekdays and weekends.

	Schedules	ON	OFF - Disables scheduling
	Weekday Settings	>	
	Weekend Settings	>	
	Mode	Heat	
	Away Settings	OFF	
	Humidity	ON	
	Humidity Settings	>	
	, ,		
	Setup Menu		Weekday Settings (Monday to Friday) - Adjust four time periods within the weekday
	Schedules	ON	program menu.
	Weekday Settings	>	Weekend Settings (Saturday to Sunday) - Adjust four time periods within the weekend
	Weekend Settings	>	program menu.
	Mode	Heat	
	Away Settings	OFF	
	Humidity	ON	
	Humidity Settings	>	
	K Weekday		Setting a schedule
	6:00am	70°	
	8:00am	66°	Time - Select the time for the schedule to be started by pressing the time on the desired
	4:00pm	72°	Cooling Temperature (Blue) - Select the cooling temperature and adjust accordingly for
	10:00pm	64°	each schedule event.
	Time		Heating Temperature (Red) - Select the heating temperature and adjust accordingly for each schedule event.
l	• 8:00am	lacksquare	



Heating/Cooling temperatures will only be displayed if thermostat has a heating/cooling type selected.



The cooling setting must be a minimum of 2°F (or 1°C) higher than the heating setting.



Heating/Cooling Target - The chosen setpoint for heating and cooling zones. Targets will be accessible in relation to the thermostat type chosen.

< v	Veekend	
6:00am	70°	70°
8:00am	66°	66°
4:00pm	72°	72°
10:00pm	64°	64°
	Heating 70	

Heating Target - Change the minimum temperature for your zone. If the temperature in the zone falls below this temperature, heating will come on. **Cooling Target** - Change the maximum temperature for your zone. If the temperature in the zone increases above this temperature, cooling will come on.



This feature is unavailable if schedules are enabled.

Mode - This option allows setting of the thermostat mode to auto, heat, cool or off.

Setup Menu Schedules	ON	Auto - The thermostat maintains cooling and heating as needed Heat - Overrides the thermostat to heat only mode
Weekday Settings	>	Cool - Overrides the thermostat to cool only mode
Weekend Settings	>	Off - Disable heating and cooling on the thermostat
Mode	Heat	
Away Settings	OFF	
Humidity	ON	
Humidity Settings	>	

Away Settings - Set the temperature for when the zone is in Away Mode. Away mode will override the schedule to a lower/higher temperature.





Humidity Settings - Configure humidity settings on the thermostat.

Setup Menu	
Schedules	ON
Weekday Settings	>
Weekend Settings	>
Mode	Heat
Away Settings	OFF
Humidity	ON
Humidity Settings	>

Fan w/ Humidity - This option will turn on your fan when there is a humidity demand.Target - When humidity is set to ON, use this setting to manually adjust your humidity target.Type - This option allows you to set the thermostat to humidify or dehumidify.

Fan Settings - Enable or disable fan settings on the thermostat.

< ا	Setup Menu	
Mod	е	Heat
Awa	y Settings	OFF
Hum	idity	ON
Hum	idity Settings	>
Fan	Settings	>
Back	dight	Bright
Degi	rees	۴F

Time Settings

Setup Menu	
Humidity	ON
Humidity Settings	>
Fan Settings	>
Time Settings	>
WiFi Settings	>
Backlight	Bright
Degrees	°F

Fan Settings: Fan Mode

OFF - Fan is off ON - Enables the fan to run constantly, regardless of whether the thermostat is calling for heating or cooling INT - This setting will set the ON/OFF time for the intermittent fan Ex: The fan will come on for 15 min every 2H. Set (Int Fan On: 15 min) & (Int Fan Off: 2H)

Auto Time - When connected to a 2.4 GHz Network the time displayed on the THM-0600's will be associated with the time zone you have chosen. Time - EManual time input (24 hour clock) Day of the Week - Manual day input (Mon, Tue, Wed, Thu, Fri, Sat, Sun) Timezone - Select the time zone for your area.

STANDARD TIMEZONES

Atlantic Standard Time	AST	GMT-4
Eastern Standard Time	EST	GMT-5
Central Standard Time	CST	GMT-6
Mountain Standard Time	MST	GMT-7
Pacific Standard Time	PST	GMT-8
Alaskan Standard Time	AST	GMT-9
Hawaiian Standard Time	HST	GMT-10

DAYLIGHT SAVINGS

Atlantic Daylight Time	ADT	GMT-3
Eastern Daylight Time	EDT	GMT-4
Central Daylight Time	CDT	GMT-5
Mountain Daylight Time	MDT	GMT-6
Pacific Daylight Time	PDT	GMT-7



WIFI Settings - Once you have selected the appropriate network and you have entered the correct password for that 2.4GHz network, pressing Ready will establish a connection to the Wi-Fi network. Attempting to connect to Wi-Fi the display will say Updating Settings, before showing Connecting to Wi-Fi, Please Wait. The controller is now trying to connect to Wi-Fi and it may take upwards of 120 seconds. If the controller backs out of the WI-FI Settings then just re-enter the page and wait. After it has counted down it will display either Now Connected to, Server. It is now connected to its 2.4GHz network and the Wi-Fi symbol on the Main Screen will appear soon after. If the connection was unsuccessful it will display Press to Connect, Ready. Click on Ready and begin the connection process again.

<	Setup Menu	
Hum	nidity	ON
Hum	idity Settings	>
Fan	Settings	>
Time	e Settings	>
WiFi	Settings	>
Back	dight	Bright
Deg	rees	°F

ľ

Wi-Fi Password - Input the password for the 2.4 GHz SSID network that you are connecting to. (capital letters, special characters, numbers and lower case characters all available).

Wi-Fi SSID Manual Entry – This is where you can manually input the 2.4GHz SSID network that you want to connect to, use this method if the network does not auto populate when you perform the Wi-Fi SSID Scan. Ensure that you input this network exactly how it would appear, including spaces, numbers, capital or lowercase letters and or special characters.

Wi-Fi SSID Scan – Pressing this will allow the SGL-0600 to actively scan for all available networks that you can choose from, and then you may select the 2.4 GHz network that you wish to connect to.

Press to Connect - Once you have selected the appropriate network and you have entered the correct password for that 2.4GHz network, pressing Connect Now will establish a connection to the Wi-Fi network.



If the connection is successful the option will display "Server". If the connection is not successful the option will display ready. If it displays "Wi-Fi" you may need to open port 2200 and 1355 on your network router.

Backlight - This option adjusts the brightness of the thermostat screen during idle.

Setup Menu	
Mode	Heat
Away Settings	OFF
Humidity	ON
Humidity Settings	>
Fan Settings	>
Backlight	Bright
Degrees	۴

Degrees - This option will change the thermostat temperature to either Celsius (°C) or Fahrenheit (°F).

Setup Menu	
Mode	Heat
Away Settings	OFF
Humidity	ON
Humidity Settings	>
Fan Settings	>
Backlight	Bright
Degrees	٩F

°**C** - Display temperatures in Celsius °**F** - Display temperatures in Fahrenheit Control Systems Inc.



SensorLinx[™] Mobile App

The Sensorlinx[™] mobile app is available for Apple iOS (APP Store) and Android® devices (Google Play). The mobile app allows for remote monitoring and control for HBX Controls devices.

Now available on the Apple App Store and Google Play

For detailed instructions on setting up the SensorLinx mobile app please refer to the SensorLinx app manual

Creating & Managing Buildings

Under My Buildings will be a list of the available Building locations to choose from. Each building will have the total number of HBX devices linked to that building, name, and address.

To add a Building, go to the Plus Symbol on the right of My Buildings and this will go to the Create Building page. Each of the fields under Create Building must be filled out to proceed, but they can be altered later under the Building Icon. Pressing Cancel or hitting the back button will delete the previous information on the page and will go back to My Buildings.

Once a Building has been created you will be redirected to the Devices page. This page will show all the devices linked to the Building as well as the outside temperature and current forecast based on the address information you've entered. If no devices have been added yet it will say No devices and provide a button to Link Devices.



HBX SGL-0600 Single Zone Control

<	Create Bui	ding	CANCEL	0
	DING NAME			
	UNTRY			
S	elect Country		-	÷
	DING ADDRESS			
	VINCE/STATE			
CITY	Ý	POSTAL	ZIP CODE	
		Continuo		

Control Systems Inc.

HBX

HBX SGL-0600 Single Zone Control

Version 1.0.0

Creating & Managing Devices

Link Devices will go to a page that will say Scan Device QR Code, Enter Manually and Finished. The QR Code on the physical device can be scanned under this screen to enter in the device's information or it can be entered in manually by using the Sync Code and Device PIN. Both the Sync Code and Device PIN will be on the device itself. Once the information has been added click Add Device and then Finish. The device added and any devices linked together will populate under Devices. If any of the devices do not appear under this page then go to the Plus Symbol next to the outside weather to add further devices.

2 Each device will have its targets, sensor readings and demands displayed on this page. Clicking on any device will allow for these targets and demands to be changed.

The name and type of the device

A green dot next to the device name will indicate that the device is connected and communicating to the network. A caution symbol next to the device name will indicate that the device is no longer communicating to the network.

This will bring up with the Create Building page or the Link Device page to add additional buildings and devices.



Goes to Account Settings. Changes to a user's account are made here.





2 Stage Heating and 2 Stage Cooling with External 24VAC





5 6

Ť ΤН 3

3





Single Stage Heating and Cooling





Limited Warranty

HBX Controls warrants each of its products to be free from defects in workmanship and materials under normal use and service for a period of 24 months from date of manufacture or 12 months from date of purchase from an HBX Authorized Dealer, if within the above documented period after date of manufacture.

If the product proves to be defective within the applicable warranty period, HBX on its sole discretion will repair or replace said product. Replacement product may be new or refurbished of equivalent or better specifications, relative to the defective product. Replacement product need not be of identical design or model. Any repair or replacement product pursuant to this warranty shall be warranted for not less than 90 days from date of such repair, irrespective of any earlier expiration of original warranty period. When HBX provides replacement, the defective product becomes the property of HBX Controls.

Warranty Service, within the applicable warranty period, may be obtained by contacting your nearest HBX Controls office via the original Authorized Agent and requesting a Return Material Authorization Number (RMA #). Proof of purchase in the form a dated invoice/receipt must be provided to expedite the issuance of a Factory RMA.

After an RMA number has been issued, the defective product must be packaged securely in the original or other suitable shipping package to ensure that it will not be damaged in transit. The RMA number must be visible on the outside of the package and a copy included inside the package. The package must be mailed or otherwise shipped back to HBX with all costs of mailing/shipping/insurance prepaid by the warranty claimant.

Any package/s returned to HBX without an approved and visible RMA number will be rejected and shipped back to purchaser at purchaser's expense. HBX reserves the right, if deemed necessary, to charge a reasonable levy for costs incurred, additional to mailing or shipping costs.

Limitation of Warranties

If the HBX product does not operate as warranted above the purchasers sole remedy shall be, at HBX's option, repair or replacement. The foregoing warranties and remedies are exclusive and in lieu of all other warranties, expressed or implied, either in fact or by operation of law, statutory or otherwise, including warranties of merchantability and fitness for a particular purpose/application. HBX neither assumes nor authorizes any other person to assume for it any other liability in connection with the sale, installation maintenance or use of HBX Controls products.

HBX shall not be liable under this warranty; if its testing and examination discloses that the alleged defect in the product does not exist or was caused by the purchasers or third persons misuse, neglect, improper installation or testing, unauthorized attempts to repair or any other cause beyond the range of intended use, or by accident, fire, lightning or other hazard.

Limitation of Liability

In no event will HBX be liable for any damages, including loss of data, loss of profits, costs of cover or other incidental, consequential or indirect damages arising out of the installation, maintenance, commissioning, performance, failure or interruption of an HBX product, however caused and on any theory of liability. This limitation will apply even if HBX has been advised of the possibility of such damage.

Local Law

This limited warranty statement gives the purchaser specific legal rights. The purchaser may also have other rights which vary from state to state in the United States, from Province to Province in Canada and from Country to Country elsewhere in the world.

To the extent this Limited Warranty Statement is inconsistent with local law, this statement shall be deemed modified to be consistent with such local law. Under such local law, certain disclaimers and limitations of this statement may not apply to the purchaser. For example, some states in the United States, as well as some governments outside the United States (including Canadian Provinces), may:

Preclude the disclaimers and limitations in this statement from limiting the statutory rights of a consumer (e.g. United Kingdom);

Otherwise restrict the ability of a manufacturer to enforce such disclaimers or limitations; or

Grant the purchaser additional warranty rights which the manufacturer cannot disclaim, or not allow limitations on the duration of implied warranties.

HBX Central Suptame Inc.	
	HBX SGL-D600 Single Zone Control Version 1.0.0
NOTES	

HBX Control Systems Inc.	HRY SEL-DEDD Single Zang Contro
NOTES	Version 1.0.0

Phone: +1 (403) 720-0029 Fax: +1 (403) 720-0054 Email: info@hbxcontrols.com Web: www.hbxcontrols.com

Toll Free Technical Support: +1 (855) 410 2341





HBX Control Systems Inc. 4516 - 112th Avenue SE Calgary, AB Canada T2C 2K2

© HBX Control Systems Inc. 2021